

Changing the Limits for Altus Motors

Flowchart

IMPORTANT NOTES:

This procedure will only work if you have an existing transmitter that has already been programmed to the motor.

