

Deleting Channels or Transmitters from Altus & Orea Motors Flowchart

IMPORTANT NOTES:

This procedure will only work if the motor you want to delete is programmed to at least 2 Channels or Transmitters.

